



How to Descale Your Domestic Dishwasher Using Jasol's Scale Off 40

What You'll Need:

- 250ml of Jasol Scale Off 40
- A dishwasher-safe cup or bowl (preferably glass or ceramic)
- An empty dishwasher

Safety First!


- Wear **gloves, glasses, face shield** and **apron**
- Ensure good ventilation
- Do **not** mix Scale Off 40 with any other chemicals or detergents
- Keep out of reach of children and pets



1


Ensure the dishwasher is free from:

- Dishes
- Cutlery
- Tablets
- Chemicals



2

Pour **1 cup (250ml)** of Scale Off 40 into a dishwasher safe cup or bowl



3

Place the cup upright in the top or bottom rack of the empty dishwasher



4

Set your dishwasher to run on the **longest** and **hottest** cycle (usually labelled as "**Heavy**" or "**Intensive**")



5

Close the door and start the cycle as normal. The Scale Off 40 will release gradually during the wash, descaling the internal parts of your machine.

6

Allow the cycle to run to completion. Do not interrupt it.

7

Inspect interior results and loosen any remaining buildup with a scraper, scourer or cloth



8

If there is any residual chemical smell, run an empty rinse cycle to flush it out.

9

- Descale **monthly** in hard water areas
- Descale every **2-3 months** for regular maintenance